

ACTIVATION INSTRUCTIONS:

1. OPEN THE SIM CARD COVER ON THE SIDE OF THE DEVICE. YOU WILL SEE THE SIM CARD AND AN ON AND OFF SWITCH. THE DEVICE ARRIVES IN THE OFF POSITION. TURN THE SWITCH TO ON BY SLIDING IT TO THE LEFT. WAIT FOR THE RED AND BLUE INDICATOR LIGHTS TO FLASH.
2. PLACE THE COVER BACK ON.
3. THE DEVICE MUST BE OUTSIDE FOR THE FIRST LOCATION.



- THE PLATFORM WILL SHOW THE DEVICE AS ACTIVATED WITH BATTERY LEVEL PERCENTAGE UNDER THE SIM STATUS AND THE MAP WILL POPULATE WHEN THE DEVICE COMES ONLINE AND GETS A LOCATION. (IT MAY TAKE UP TO 10 MINUTES)
- THE SYSTEM WILL LOCATE THE DEVICE ONCE A DAY, EVERY 25 HOURS.
- MAKE SURE TO POSITION THE MODULE WITH THE LABEL FACING DOWN WITH NO METAL DIRECTLY ABOVE IT.



RECOVER FEATURE. THE ONLY TIME YOU WOULD SELECT THE DEVICE AND CLICK THE **RECOVER** ICON IS IN THE EVENT YOU WOULD NEED TO RECOVER THE VEHICLE.

1. FIRST SELECT THE DEVICE, THEN HIT THE RED RECOVER BUTTON FROM THE COMMAND BAR ICON LIST.
2. SELECT THE LIVE RECOVERY TIME. IT CAN BE: 15, 30, 60, 90 OR 120 MINUTES, THEN SELECT CONFIRM.
3. LIVE TRACKING WILL BEGIN AT THE SCHEDULED DAILY LOCATE TIME.

Please note that the use of this recovery feature will void the manufactures warranty. This feature may drain the devices battery and affect the performance of the device in the future.



Contains FCC ID: XMR201808EC25AF
Contains IC ID: 10224A-2018EC25AF